

# JINBEI インテグレートッドホットシュー メーカー対応確認表

| Canon        | Nikon | SONY     | FUJI      | Panasonic | OLYMPUS         |
|--------------|-------|----------|-----------|-----------|-----------------|
| 1D           | D4s   | α 1      | X-A5      | G8        | E-M1 Mark II    |
| 1D Mark III  | D5    | α 9      | X-A7      | G9        | E-M1 Mark III   |
| 1D Mark IV   | D800  | α 9 II   | X-E3      | G99       | E-M1X           |
| 1Ds          | D810  | α 99II   | X-E4      | GH5       | E-M5 Mark II    |
| 1Ds Mark II  | D850  | α 6000   | X-S10     | GH5M2     | E-M5 Mark III   |
| 1Ds Mark III | D780  | α 6300   | X-Pro2    | GH5s      | E-M10 Mark III  |
| 1DX          | D750  | α 6500   | X-Pro3    | GH6       | E-M10 Mark IIIS |
| 1DX Mark II  | D700  | α 7      | X-T20     | S1        | E-M10 Mark IV   |
| 1DX Mark III | D610  | α 7C     | X-T200    | S1R       |                 |
| 5            | D600  | α 7R     | X-T30     | S1H       |                 |
| 5D           | D500  | α 7S     | X-T100    | S5        |                 |
| 5D Mark II   | D6    | α 7II    | X-T1      | S5II      |                 |
| 5D Mark III  | D60   | α 7SII   | XT-2      |           |                 |
| 5Ds          | D90   | α 7R II  | XT-3      |           |                 |
| 5DsR         | D3200 | α 7III   | XT-4      |           |                 |
| 5D Mark IV   | D3500 | α 7S III | XT-5      |           |                 |
| 6D           | D5600 | α 7R III | X-H1      |           |                 |
| 6D Mark II   | D7000 | α 7RIV   | X-H2      |           |                 |
| 7D           | D7100 |          | GFX100    |           |                 |
| 7D Mark II   | D7200 |          | GFX100s   |           |                 |
| 50D          | D7500 |          | GFX50R    |           |                 |
| 60D          | Df    |          | GFX50s    |           |                 |
| 70D          | Z5    |          | GFX50s II |           |                 |
| 80D          | Z6    |          |           |           |                 |
| 90D          | Z50   |          |           |           |                 |
| 100D         | Z6II  |          |           |           |                 |
| Kiss X5      | Z7    |          |           |           |                 |
| Kiss X10     | Z7II  |          |           |           |                 |
| Kiss X10i    | Zfc   |          |           |           |                 |
| Kiss X90     | Z9    |          |           |           |                 |
| Kiss M       |       |          |           |           |                 |
| R            |       |          |           |           |                 |
| Ra           |       |          |           |           |                 |
| RP           |       |          |           |           |                 |
| R3           |       |          |           |           |                 |
| R5           |       |          |           |           |                 |
| R6           |       |          |           |           |                 |
| R6 II        |       |          |           |           |                 |
| R7           |       |          |           |           |                 |
| R8           |       |          |           |           |                 |
| R9           |       |          |           |           |                 |
| R10          |       |          |           |           |                 |
|              |       |          |           |           |                 |
|              |       |          |           |           |                 |
|              |       |          |           |           |                 |
|              |       |          |           |           |                 |
|              |       |          |           |           |                 |
|              |       |          |           |           |                 |